

Tel: 01909 499499
Email: sales@woodside.uk
Web: www.woodside.uk

Woodside

FUSION LTD



1. Locate centre of door opening and grasp firmly.

2. Place other hand on the roof joint with Black String.


3. Push joint away from the body and up at the same time as pulling top of tent towards your body until roof pops out. Walk into the tent at the same time.

4. Keep hand on roof joint and place other hand onto side joint and push snap outwards.



5. Repeat 4 & 5 for the other two sides.



TAKING DOWN THE TENT
Support roof joint and pull on rod close to each side joint. Walk out of the tent collapsing the roof joint.



ALWAYS REMEMBER TO GUY THE TENT



Tents fitted with rear centre zip use rear string on back wall to tension rear panel when zip is open. Before popping out the rear wall centre joint - Feed string under pipe/cable etc. and clip to 'D' ring on the other side of the tent. Then pop out centre joint. String under the cable/pipe etc. also acts as an anchor for the tent.